



Použitie :

Tachodynamo

03.39.373	1,2	3	6
03.39.362	1,3	1,7	3,81
03.39.349-1	1,3	1,7	4,5
03.39.349-2	1,3	1,7	4,5
03.39.330	2	2	6,5
03.39.129	2	3	7,5
03.39.129a	2	3	7,5
03.39.327	2	3	7,5
03.39.237	2	3	9,7
03.39.246	2,5	4	10
03.39.251	2,9	3,3	10,5
03.39.151a	3	3	10
03.39.245	3	3	11,2
03.39.252	3,2	5	13

Litze gegenseitig

Litze gegenseitig

39

